



1-860-578-12 (1-723-574-12)

G

10

SONY

(B) **4**

~ G Board Location Table (B Side) ~

DIODE		D6020	J - 8	D6754	K - 7
D6001	C - 11	D6021	D - 8	IC	
D6002	C - 11	D6022	I - 8	IC6002	F - 8
D6003	C - 10	D6023	G - 8	IC6003	D - 9
D6005	L - 2	D6024	G - 8	IC6004	F - 10
D6006	G - 8	D6027	G - 10	IC6005	I - 7
D6007	C - 8	D6028	F - 11	IC6006	L - 7
D6008	F - 8	D6029	D - 11	IC6007	J - 7
D6009	D - 10	D6031	D - 8	IC6009	K - 7
D6011	K - 4	D6032	I - 10	IC6010	J - 7
D6010	C - 9	D6033	G - 7	IC6750	M - 7
D6011	C - 9	D6034	F - 7	TRANSISTOR	
D6012	D - 9	D6035	G - 9	Q6001	C - 11
D6013	D - 9	D6036	F - 9	Q6002	H - 10
D6014	E - 9	D6037	G - 8	Q6003	G -9
D6015	E - 8	D6038	F - 9	Q6004	F - 9
D6016	E - 11	D6102	M - 9	Q6008	H - 11
D6017	H - 10	D6750	M - 8	Q6010	H - 10
D6018	H - 10	D6751	M - 9	Q6014	G 7
D6019	H - 10	D6753	M - 9	Q6752	L - 8